GRUNDFOS DATA BOOKLET

DW

Dewatering pumps 50 Hz



Contents

| Introduction | |
|--|--|
| Introduction Applications | 3 3 |
| Pumped liquids | 3 |
| Constructional features | 3 |
| Identification | |
| Type key | 5 |
| Selection of pump | |
| Ordering a pump | 6 |
| Performance range | |
| Performance range | 7 |
| Product range | |
| Product numbers | 8 |
| Construction | |
| Construction Construction overview | 11 |
| Pump Motor | 12 13 |
| Material specification | 14 |
| Sectional drawings | 15 |
| | |
| Product description | |
| Integrated level control | 21 |
| Integrated level control Non-return valve Frequency converter operation | 21 22 |
| Integrated level control Non-return valve | 21 |
| Integrated level control Non-return valve Frequency converter operation | 21 22 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts | 21 22 22 22 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions Certificates | 21 22 22 23 23 23 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions | 21 22 22 23 23 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions Certificates | 21 22 22 23 23 23 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions Certificates Witness test Performance curves/ Technical data | 21 22 22 23 23 23 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions Certificates Witness test Performance curves/ Technical data DW.50.07, DW.50.08 and DW.50.09 | 21 22 22 23 23 23 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions Certificates Witness test Performance curves/ Technical data DW.50.07, DW.50.08 and DW.50.09 DW.65.27, DW.65.39, DW.100.39 and DW.100.66 DW.100.110, DW.150.110, DW.100.200 and | 21 22 22 23 23 23 23 23 24 25 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions Certificates Witness test Performance curves/ Technical data DW.50.07, DW.50.08 and DW.50.09 DW.65.27, DW.65.39, DW.100.39 and DW.100.66 | 21 22 22 23 23 23 23 23 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions Certificates Witness test Performance curves/ Technical data DW.50.07, DW.50.08 and DW.50.09 DW.65.27, DW.65.39, DW.100.39 and DW.100.66 DW.100.110, DW.150.110, DW.100.200 and DW.150.200 Accessories | 21 22 22 23 23 23 23 23 24 25 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions Certificates Witness test Performance curves/ Technical data DW.50.07, DW.50.08 and DW.50.09 DW.65.27, DW.65.39, DW.100.39 and DW.100.66 DW.100.110, DW.150.110, DW.100.200 and DW.150.200 | 21 22 22 23 23 23 23 23 24 25 |
| Integrated level control Non-return valve Frequency converter operation Testing Curve charts and technical data How to read the curve charts Curve conditions Certificates Witness test Performance curves/ Technical data DW.50.07, DW.50.08 and DW.50.09 DW.65.27, DW.65.39, DW.100.39 and DW.100.66 DW.100.110, DW.150.110, DW.100.200 and DW.150.200 Accessories | 21 22 22 23 23 23 23 24 25 26 |

Introduction

This data booklet deals with Grundfos dewatering pumps, type DW.



Fig. 1 DW pumps for free-standing installation

The pumps are specially designed to meet the highest demands in construction, building services and industrial applications where there is a need for pumping dirty water with a high content of abrasive particles.

In order to achieve optimum performance and a very high reliability, the DW pumps are made of high-quality materials that provide maximum resistance to wear. For further details on construction, see pages 11 and 13.

Applications

The Grundfos DW pumps are typically used for the transfer of the following liquids:

- · drainage water
- surface water
- groundwater
- · water containing abrasives.

The DW pumps are suitable for operation in harsh environments, such as

- · construction building sites
- · basement garages
- drainage pits
- · low-lying rainwater catchment areas
- power stations
- steel works
- · ship yards
- onboard ships
- fish ponds
- · process industry, etc.

Pumped liquids

The DW pumps are specifically designed for pumping dirty water with a high content of abrasives, such as drill cuttings and sand.

Particle size

The DW pumps can handle all solids that can pass through the inlet strainer:

| Pump type | Number of holes | Hole size [mm] |
|--|-----------------|-------------------|
| DW.50.08 | 36 | Ø8 |
| DW.50.07 DW.50.09 | 39 | 8 x 32 |
| DW.65.27 DW.65.39 DW.100.39 DW.100.66 | 48 | 7 x 30 |
| DW.100.110 DW.150.110 | 165 | 10 x 30 |
| DW.100.200 DW.150.200 | 220 | 10 x 30 |

Liquid temperature

0 °C to +40 °C.

pH-value

5 to 8.

Density of pumped liquid

Maximum 1100 kg/m³.

Constructional features

Automatic operation

The DW pumps are available with integrated level control which starts the pump automatically when the built-in electrodes come into contact with water, and it stops the pump when the water level has fallen below the inlet strainer.

High reliability

High-grade materials

The DW pumps are made entirely of high-grade non-corrosive materials.

Heavy-duty ball bearings

All ball bearings are greased for life.

Double shaft seal system

The pumps have a double shaft seal system in an oil chamber which ensures trouble-free operation.

Integrated cooling jacket

An integrated cooling jacket helps keep the motor temperature low.

Overload protection

The pumps incorporate overload protection.

Integrated thermal protection

The motors incorporate thermal switches in the stator windings.

Versatility

Suitable for many applications

The DW pumps are suitable for a wide range of applications. See section **Applications** on page 3.

Discharge connection

To meet customer demands, the pump discharge is available with the following connection types:

- · hose connection
- · Storz coupling
- · threaded connection.

Portable compact design

The DW pumps have a compact design and a low weight. Furthermore, only one cable is connected to the pump, which means that no additional sensor cable is required.


Maintaining the performance

To maintain the high performance in case of wear, the diffuser can easily be adjusted against the impeller with the staybolts.

Service-friendly design

Wear parts are easy to replace without special tools.

Type key



Nameplate




Fig. 2 DW nameplate

| Pos. | Description |
|------|------------------------------------|
| 1a | Type designation |
| 1b | Nominal diameter of discharge port |
| 1c | Rated shaft power |
| 1d | Code, level control |
| 1e | Number of phases |
| 1f | Code, high-pressure version |
| 2 | Product number |
| 3 | Weight |
| 4 | Maximum head |
| 5 | Rated speed |
| 6 | Number of phases |
| 7 | Frequency |
| 8 | Rated power input |

| Pos. | Description |
|------|----------------------------|
| | • |
| 9 | Rated shaft power |
| 10 | Rated voltage, Δ |
| 11 | Rated current, Δ |
| 12 | Enclosure class to IEC |
| 13 | Enclosure class to CEE |
| 14 | Maximum flow rate |
| 15 | Production year and week |
| 16 | Maximum liquid temperature |
| 17 | Maximum installation depth |
| 18 | Insulation class |
| 19 | Rated current, Y |
| 20 | Rated voltage, Y |
| | |

01 9993 4509

Selection of pump

Ordering a pump

The complete range of DW pumps, including product numbers, can be found in section *Product range* on pages 8 to 10.

When ordering a pump, you need to take the aspects below into consideration:

Required flow and head

Maximum flow and maximum head can be found in section *Performance curves/ Technical data* on pages 24 to 26.

Particle size

The maximum size of particles that the DW pumps can handle can be found in section *Particle size* on page 3.

Installation depth

The maximum installation depth can be found in section Performance curves/ Technical data on pages 24 to 26.

Operation type

The DW pumps are available with automatic level control or for manual operation.

Pumps with automatic level control can be identified by the letter "A" in the pump type key.

Pumps without automatic level control, but which are prepared for an external control box, can be fitted with a float switch to enable automatic level control.

Discharge connection type

The following discharge connections are available:

- · hose connection
- Storz coupling
- · threaded connection.

Alternative power cables

As standard, the cables are 20 metres long.

Other cable lengths are available on request.

The number and dimension of cables depend on the motor size. All cables are rubber cables type H07RN-F.

| Cable size [mm ²] | Outer cable diameter [mm] | Schuko plug |
|-------------------------------|---------------------------|-------------|
| 3 x 1.5 | 9.9 | No |
| 4 x 1.5 | 11.1 | No |
| 3 x 1.5 | 9.9 | Yes |
| 4 x 2.5 | 13.3 | No |
| 4 x 10 | 23.5 | No |

Plug type

The following plug types are available:

- · Schuko plug
- CEE plug
- no plug.

Accessories

Depending on the installation type, accessories may be required.

See section *Accessories* on pages 27 to 28 for selection of the correct accessories.

Note: Accessories are not fitted from factory.

Performance range




Fig. 3 Performance range DW

TM01 3305 4501

Product range

Product numbers

Pumps with aluminium pump sleeve

| | | | Е | lectrical | connectio | on | Disch | arge conr | ection | |
|-----------------------------------|--------------------------------|-----|--|-------------|----------------|-----------------------------------|-------|--|---------------------|----------------|
| Pump type | Voltage Starting [V] method | | No plug | Schuko plug | Motor starter* | Prepared for external control box | Hose | Threaded | Storz coupling half | Product number |
| | | | | gle-phase | pumps | | | | | |
| DW.50.07.1 | 1 x 230 | DOL | • | | | | | • | | 96090204 |
| DW.50.07.A1 | 1 x 230 | DOL | • | | | | | • | | 96090205 |
| DW.50.07.1 | 1 x 230 | DOL | | • | | | | | • | 96090238 |
| DW.50.07.41 | 1 x 230 | DOL | | • | | | | | • | 96090239 |
| DW.50.07.1 | 1 x 230 | DOL | The | oo nhaca | • numno | | • | | | 96090299 |
| DW.50.09.3 | 3 x 400 | DOL | 1 nr | ee-phase | pumps | 1 | | • | 1 | 96090206 |
| DW.50.09.3 | 3 x 400 | DOL | • | | | | | • | | 96090206 |
| DW.50.09.A3 | 3 x 400 | DOL | <u> </u> | | • | | | • | • | 96090207 |
| DW.50.09.3 DW.50.09.A3 | 3 x 400 | DOL | | | • | 1 | 1 | | • | 96090254 |
| DW.50.09.A3 | 3 x 400 3 x 400 | DOL | | | • | 1 | • | | _ | 96090254 |
| DW.50.09.3 | 3 x 400 3 x 230 | DOL | • | | _ | 1 | • | - | | 96090300 |
| DW.50.09.3 | 3 x 230 | DOL | • | 1 | | | • | - | | 96090277 |
| DW.65.27.3 | 3 x 400 | DOL | • | | | | | • | | 96090208 |
| DW.65.27.A3 | 3 x 400 | DOL | • | | | | | • | | 96090209 |
| DW.65.27.3 | 3 x 400 | DOL | _ | | • | | | _ | • | 96090240 |
| DW.65.27.A3 | 3 x 400 | DOL | | | • | | | | • | 96090255 |
| DW.65.27.3 | 3 x 400 | DOL | | | • | | • | | _ | 96090301 |
| DW.65.27.3 | 3 x 230 | DOL | • | | | | • | | | 96090278 |
| DW.65.27.A3 | 3 x 230 | DOL | • | | | | • | | | 96090279 |
| DW.65.39.3.H | 3 x 400 | DOL | • | | | | | • | | 96090210 |
| DW.65.39.A3.H | 3 x 400 | DOL | • | | | | | • | | 96090211 |
| DW.65.39.3.H | 3 x 400 | DOL | | | • | | | | • | 96090241 |
| DW.65.39.A3.H | 3 x 400 | DOL | | | • | | | | • | 96090256 |
| DW.65.39.3.H | 3 x 400 | DOL | | | • | | • | | | 96090302 |
| DW.65.39.3.H | 3 x 230 | DOL | • | | | | • | | | 96090280 |
| DW.65.39.A3.H | 3 x 230 | DOL | • | | | | • | | | 96090281 |
| DW.100.39.3 | 3 x 400 | DOL | • | | | | | • | | 96090212 |
| DW.100.39.A3 | 3 x 400 | DOL | • | | | | | • | | 96090213 |
| DW.100.39.3 | 3 x 400 | DOL | | | • | | | | • | 96090242 |
| DW.100.39.3 | 3 x 400 | DOL | | | • | | • | | | 96090298 |
| DW.100.39.A3 | 3 x 400 | DOL | | | • | | | | • | 96090257 |
| DW.100.39.3 | 3 x 230 | DOL | • | | | | • | | | 96090282 |
| DW.100.39.A3 | 3 x 230 | DOL | • | | | | • | | | 96090283 |
| DW.100.66.3 | 3 x 400 | DOL | • | | | | | • | | 96090214 |
| DW.100.66.A3 | 3 x 400 | DOL | • | | | | | • | | 96090215 |
| DW.100.66.3.H | 3 x 400 | DOL | • | | | | | • | | 96090232 |
| DW.100.66.A3.H | 3 x 400 | DOL | • | | | | | • | | 96090233 |
| DW.100.66.3.H | 3 x 400 | DOL | | | • | | | | • | 96090243 |
| DW.100.66.3 | 3 x 400 | DOL | | | • | | | | • | 96090244 |
| DW.100.66.A3 | 3 x 400 | DOL | | | • | | | | • | 96090259 |
| DW.100.66.3.H | 3 x 400 | DOL | | | • | | • | | | 96090303 |
| DW.100.66.3 | 3 x 400 | DOL | | | • | | • | | | 96090304 |
| DW.100.66.A3.H | 3 x 400 | DOL | ļ | | • | 1 | 1 | ļ | • | 96090258 |
| DW.100.66.3 | 3 x 230 | DOL | • | | | | • | ļ | | 96090284 |
| DW.100.66.A3 | 3 x 230 | DOL | • | | | - | • | | | 96090285 |
| DW.100.66.3.H | 3 x 230 | DOL | • | | | - | • | | | 96090286 |
| DW.100.66.3A.H | 3 x 230 | DOL | • | | | ļ | • | <u> </u> | | 96090287 |
| DW.100.110.3.H | 3 x 400 | DOL | • | | | 1 | | • | | 96090216 |
| DW.100.110.A3.H | 3 x 400 | DOL | • | | | 1 | | • | | 96090217 |
| DW.100.110.3.H DW.100.110.A3.H | 3 x 400 | Y/D | • | | | 1 | 1 | • | | 96090220 |
| LAVETUU TTU A3 H | 3 x 400 | Y/D | • | Ì | Ī | 1 | Ì | • | Ī | 96090221 |

Product range

| | | | Electrical connection | | | | Discharge connection | | | |
|-----------------|---------|--------------------|-----------------------|-------------|----------------|-----------------------------------|----------------------|----------|---------------------|----------------|
| Pump type | | Starting method | No plug | Schuko plug | Motor starter* | Prepared for external control box | Hose | Threaded | Storz coupling half | Product number |
| DW.100.110.3.H | 3 x 400 | Y/D | • | | | | | | • | 96090247 |
| DW.100.110.A3.H | 3 x 400 | DOL | | | • | | | | • | 96090260 |
| DW.100.110.3.H | 3 x 400 | DOL | | | • | | • | | | 90090305 |
| DW.100.110.3.H | 3 x 400 | DOL | • | | | | | • | | 96090324 |
| DW.100.200.3.H | 3 x 400 | DOL | • | | | | | • | | 96090224 |
| DW.100.200.A3.H | 3 x 400 | DOL | • | | | | | • | | 96090225 |
| DW.100.200.3.H | 3 x 400 | Y/D | • | | | | | • | | 96090228 |
| DW.100.200.A3.H | 3 x 400 | Y/D | • | | | | | • | | 96090229 |
| DW.100.200.3.H | 3 x 400 | DOL | • | | | • | | | • | 96090249 |
| DW.100.200.3.H | 3 x 400 | Y/D | • | | | • | | | • | 96090251 |
| DW.100.200.3.H | 3 x 400 | DOL | • | | | | | | • | 96090268 |
| DW.100.200.3.H | 3 x 400 | DOL | • | | | • | • | | | 96090306 |
| DW.100.200.3.H | 3 x 400 | Y/D | • | | | | | | • | 96090270 |
| DW.150.110.3 | 3 x 400 | DOL | • | | | | | • | | 96090218 |
| DW.150.110.A3 | 3 x 400 | DOL | • | | | | | • | | 96090219 |
| DW.150.110.3 | 3 x 400 | Y/D | • | | | | | • | | 96090222 |
| DW.150.110.A3 | 3 x 400 | Y/D | • | | | | | • | | 96090223 |
| DW.150.110.3 | 3 x 400 | DOL | | | • | | | | • | 96090246 |
| DW.150.110.3 | 3 x 400 | Y/D | • | | | • | | | • | 96090248 |
| DW.150.110.A3 | 3 x 400 | DOL | | | • | | | | • | 96090261 |
| DW.150.110.3 | 3 x 400 | DOL | • | | | • | | • | | 96090273 |
| DW.150.110.3 | 3 x 400 | DOL | | | • | | • | | | 96090307 |
| DW.150.200.3 | 3 x 400 | DOL | • | | | | | • | | 96090226 |
| DW.150.200.A3 | 3 x 400 | DOL | • | | | | | • | | 96090227 |
| DW.150.200.3 | 3 x 400 | Y/D | • | | | | | • | | 96090230 |
| DW.150.200.A3 | 3 x 400 | Y/D | • | | | | | • | | 96090231 |
| DW.150.200.3 | 3 x 400 | DOL | • | | | • | | | • | 96090250 |
| DW.150.200.3 | 3 x 400 | Y/D | • | | | • | | | • | 96090252 |
| DW.150.200.3 | 3 x 400 | DOL | • | | | | | | • | 96090269 |
| DW.150.200.3 | 3 x 400 | DOL | | | • | | • | | | 96090308 |
| DW.150.200.3 | 3 x 400 | Y/D | • | | | | | | • | 96090271 |

^{*} With motor protection, CEE plug, phase sequence tester and phase inverter.

Product range

Pumps with polypropylene pump sleeve

All DW.50.08 pumps are for direct-on-line starting.

| | | | Electrical | connection | | Disc | harge conne | | |
|-------------|----------------|---------|-------------|----------------|-----------------------------------|------|-------------|---------------------|----------------|
| Pump type | Voltage [V] | No plug | Schuko plug | Motor starter* | Prepared for external control box | Hose | Threaded | Storz coupling half | Product number |
| | | | S | ingle-phase | | ı | | l | • |
| DW.50.08.1 | 1 x 230 | | • | | | | | • | 96090200 |
| DW.50.08.A1 | 1 x 230 | | • | | | | | • | 96090201 |
| DW.50.08.1 | 1 x 230 | • | | | | | • | | 96090234 |
| DW.50.08.A1 | 1 x 230 | • | | | | | • | | 96090235 |
| DW.50.08.1 | 1 x 230 | | • | | | • | | | 96090296 |
| DW.50.08.A1 | 1 x 230 | | • | | | • | | | 96090297 |
| | | | 7 | Three-phase | pumps | | | | |
| DW.50.08.3 | 3 x 400 | | | • | | | | • | 96090202 |
| DW.50.08.A3 | 3 x 400 | | | • | | | | • | 96090203 |
| DW.50.08.3 | 3 x 400 | • | | | | | • | | 96090236 |
| DW.50.08.A3 | 3 x 400 | • | | | | | • | | 96090237 |
| DW.50.08.3 | 3 x 230 | • | | | | • | | | 96090274 |
| DW.50.08.A3 | 3 x 230 | • | | | | • | | | 96090275 |


^{*} With motor protection, CEE plug, phase sequence tester and phase inverter.

Note: Pumps without integrated motor starter for direct-on-line or star-delta starting must be connected to an external motor protection to protect the motor against overcurrent and overload.

Pumps without automatic level control, but which are prepared for an external control box, can be fitted with a float switch to enable automatic level control.

Three-phase pumps with CEE plugs are available with or without phase inverter. Single-phase pumps with plug have a Schuko plug.

Construction overview



TM04 6480 0510

Pump

Stator housing, pump sleeve and top cover

Grundfos DW pumps have stator housing, pump sleeve and top cover made of aluminium.

The DW.50.08 has a polypropylene pump sleeve.

Shaft and bearings

The rotor shaft is made of stainless steel. It rotates in an upper and a lower maintenance-free prelubricated heavy-duty ball bearing.

The DW.50.07 to DW.100.66 (0.7 to 6.6 kW) have two single-row ball bearings.

In DW.100.110 to DW.150.200 (11 and 20 kW), the lower ball bearing is a double-row ball bearing, the upper a single-row ball bearing.

Impeller

All DW pumps have a semi-open multi-vane impeller cast in high-chromium stainless steel for maximum wear resistance. Hardness: 550 HB.

The impeller is provided with back vanes to protect the shaft seal against abrasives.

The three large motor sizes (6.6, 11 and 20 kW) can have two impellers connected in series to obtain high heads.

Wear parts

Because of the tough applications, the real strength of the DW pumps is the rubber parts.

In order to provide protection against abrasives in the pumped liquid, the impeller is fitted between two rubber parts.

A rubber-coated back plate above the impeller protects the bottom of the oil chamber against wear.

As the rubber is soft compared to the impeller, it allows abrasives to intrude the surface as the impeller passes the particles.

As the diffuser becomes worn, it is easily adjusted against the impeller with the staybolts to maintain the high performance.

In pumps with two impellers, a rubber-coated intermediate plate is fitted between the two impellers.

A rubber liner protects against wear inside the pump aluminium sleeve where the velocity is highest.

Shaft seal

In the DW.50.08 (polypropylene pump sleeve), the shaft seal system is a grease-filled bushing with lip seals in both ends.

The DW.50.07 to DW.100.66 (0.7 to 6.6 kW, aluminium pump sleeve) have a combination of a mechanical seal and a lip seal. The primary seal is made of silicon carbide/silicon carbide, and the secondary seal is a lip seal.

The DW.100.110 to DW.150.200 (11 and 20 kW, aluminium pump sleeve) have two mechanical seals. The primary seal is made of silicon carbide/silicon carbide and the secondary seal of carbon/aluminium oxide.


The space between the primary and secondary seals is filled with oil or grease (DW.50.08).

Integrated level control ("A" versions)

Note: The following does not apply to DW.50.08.A pumps as they are fitted with a float switch.

Automatic level control is achieved by means of moisture sensing electrodes monitoring the water level in the pit/sump to be drained.

The control voltage is 24 V.



TM01 3435 9998

Fig. 4 Integrated level control

| Pos. | Description |
|------|-------------------------|
| 1 | Electrode unit |
| 2 | Air valve |
| 3 | Electrodes |
| 4 | Water level compartment |
| 5 | Valve body |
| 6 | Valve rubber |
| 7 | Water rising channel |
| | |

Electrode unit (1)

The electrode unit is located in the pump top cover and also functions as a switch for easy changeover between automatic operation with level control, "A", and continuous (manual) operation, "C". The unit comprises two electrodes (3).

Air valve (2)

The air valve is located in the pump top cover close to the electrode unit (1). It consists of valve body (5), valve rubber (6) and valve cap.

Electrodes (3)

The two electrodes, one short and one long, protrude downwards into the water level compartment (4).

Short electrode: Starts the pump.

Long electrode: Keeps the pump running.

The two electrodes ensure that the pump keeps running if the water level in the water level compartment (4) varies a little or if the pump is tilted during operation.

Water level compartment (4)

The compartment is vertically separated from the stator housing.

Motor

The motor is a watertight, totally enclosed two-pole motor for 50 Hz with voltage tolerances of - 10 %/+ 6 %.

Enclosure class: IP68.

Insulation class: F (155 °C).

Maximum number of starts per hour: 30.

starter incorporate an overcurrent relay.

All motors are designed for direct-on-line starting and fitted with thermal overload switches in the stator windings that break the circuit at 130 °C.

11 and 20 kW pumps are also available for star-delta starting. All 11 and 20 kW pumps with integrated motor

The DW pumps are supplied with 20 metres of cable, type H07RN-F.

Overload protection

The pumps incorporate overload protection. Furthermore, pump types DW.100.110 to DW.150.200 have an overload circuit to protect the motor in case the impeller is seized up due to debris.

Cooling

Sufficient cooling is achieved by means of the liquid flow inside the pump sleeve along the motor casing.

Material specification

See also the sectional drawings of the various pump types on pages 15 to 20.

| Description | Material | DIN WNr. | ASTM/AISI |
|--|--|----------------|--------------------|
| Stator housing Pump sleeve Discharge connection Top cover | All models, except DW.50.08: Aluminium castings. DW.50.08 has a polypropylene pump sleeve. | 1712:GA15:10Mg | ASTM B26SG 100A |
| Motor cable | 20 metres, type H07RN-F. | | |
| Impeller | Stainless steel (nickel-chromium) 550 HB. | | |
| Shaft | Stainless steel. | 1.4021 | AISI 420 |
| | DW.50.07 to DW.100.66: • Two prelubricated single-row heavy-duty ball bearings. | | |
| Bearings | DW.100.110 to DW.150.200 (11 and 20 kW): Prelubricated heavy-duty ball bearings. The lower ball bearing is a double-row ball bearing. The upper bearing is a single-row ball bearing. | | |
| Shaft seals | DW.50.08 with polypropylene pump sleeve: • Grease-filled seal bushing and a lip seal in both ends. DW.50.07 to DW.100.66 with aluminium pump sleeve: • Combination of a mechanical seal and a lip seal. • Primary seal: mechanical seal, silicon carbide/silicon carbide. • Secondary seal: lip seal. | | |
| | DW.100.110 to DW.150.200 (11 and 20 kW): • Primary seal: silicon carbide/silicon carbide. • Secondary seal: carbon/aluminium oxide. | | |
| Bottom plate and strainer | All models, except DW.50.08: stainless steel. DW.50.08 has a polypropylene strainer. | 1.4301 | AISI 304 |
| Wear parts | Nitrile rubber. | | |
| Screws | Stainless steel. | 1.4301 | AISI 304 |

Sectional drawings

DW.50.07.(A)1/09.(A)3




Fig. 5 DW.50.07.(A)1/09.(A)3

TM01 3361 5001

DW.65.27.(A)3




Fig. 6 DW.65.27.(A)3

MO1 4536 50

DW.65.39.(A)3.H/100.39.(A)3




Fig. 7 DW.65.39.(A)3.H/100.39.(A)3

MO1 3363 500

DW.100.66.(A)3.H/100.66.(A)3




Fig. 8 DW.100.66.(A)3.H/100.66.(A)3

MO1 3364 50

DW.100.110.(A)3.H/150.110.(A)3




Fig. 9 DW.100.110.(A)3.H/150.110.(A)3

MO13365 50

DW.100.200.H/150.200




Fig. 10 DW.100.200.H/150.200

M01 3366 50

Product description

Integrated level control

Pumps with integrated level control have a switch for setting the pump to automatic operation, "A", or to continuous (manual) operation, "C".

When the pump has been lowered into the pit, sump, etc., switch on the power supply. The integrated level control system now automatically starts and stops the pump, depending on the water level.

Note: The DW.50.08 pumps for automatic operation are supplied with a float switch with 0.5 metres of cable. The float switch is fitted to the top cover.

How it works

The following description does not apply to DW.50.08.A pumps, as they are fitted with a float switch.

Start conditions




Fig. 11 Start conditions

When the water level rises, the pump is filled with water, and the built-in electrodes come into contact with water. When this happens, an electric circuit switches on the pump.

Pump in operation




Fig. 12 Pump in operation

The water level decreases when the pump is running, but due to the pressure in the pump, the water level in the electrode chamber remains high, and the pump continues to run.

Stop conditions




Fig. 13 Low water level

The pump will start sucking air when the water level has fallen below the inlet strainer. Because of the low pump pressure, air is sucked into the electrode chamber. The water level in the electrode chamber decreases, but the pump will run as long as the long electrode is in contact with water. When the water level has fallen below the long electrode, the electric circuit is broken, and the pump stops.

Non-return valve

When A models are used for automatic operation in deep pits/sumps, a non-return valve must the fitted immediately after the discharge port to prevent backflow and thus intermittent operation when the pit/sump has been drained. See fig. 14.



Fig. 14 Pump installed in pit with long vertical riser pipe or hose

Product description

Frequency converter operation

The DW pumps with integrated motor starter should not be connected to a frequency converter, as this may result in damage to the motor.

Frequency converter operation will often expose the motor insulation system to a heavier load and cause the motor to be more noisy than usual due to eddy currents caused by voltage peaks.

In addition, large motors driven via a frequency converter will be loaded by bearing currents.

Testing

All pumps are tested before leaving the factory. The factory test report is based on ISO 9906, Annex A. Test reports can be ordered together with the pump or separately based on the pump serial number.

Other tests or third-party inspection certificates are available on request.

How to read the curve charts




Fig. 15 Curve chart

Curve conditions

The guidelines below apply to the curves in the performance charts on pages 24 to 26.

- Tolerances according to ISO 9906, Annex A.
- The curves apply to the pumping of airless water at a temperature of +20 °C and a kinematic viscosity of 1 mm²/s (1 cSt).
- In the case of other densities than 1000 kg/m³, the discharge pressure is proportional to the density.
- When pumping liquids with a density higher than 1000 kg/m³, pumps with correspondingly higher outputs must be used.
- · The curves must not be used as guarantee curves.

Certificates

Certificates have to be confirmed for every order and are available on request:

- Certificate of compliance with the order (EN 10204-2.1)
- Pump test sheet.

Witness test

It is possible for the customer to witness the testing procedure according to ISO 9906.

The witness test is not a certificate and will not result in a written statement from Grundfos. The witness test itself is the only guarantee that everything is carried out as prescribed in the testing procedure.

If the customer wants to witness the test of the pump performance, this request must be stated in the order.

Performance curves/ Technical data


DW.50.07, DW.50.08 and DW.50.09



DW.50.08




DW.50.07/ DW.50.09



TM04 6009 4609

Dimensions, weight and max. installation depth



| | Pump type | H [mm] | D [mm] | M [mm] | \$ [mm] / [inch] | Weight* [kg] | Max. installation depth [m] |
|------|-------------|-----------|-----------|-----------|---------------------|-----------------|-----------------------------|
| | DW.50.07.1 | 395 | 210 | 212 | 50 / 2 | 17 | 20 |
| | DW.50.07.A1 | 395 | 210 | 212 | 50 / 2 | 18 | 20 |
| | DW.50.08.1 | 432 | 200 | 200 | 50 / 2 | 13 | 5 |
| | DW.50.08.A1 | 432 | 200 | 200 | 50 / 2 | 13 | 5 |
| 3998 | DW.50.08.3 | 432 | 200 | 200 | 50 / 2 | 13 | 5 |
| 347 | DW.50.08.A3 | 432 | 200 | 200 | 50 / 2 | 13 | 5 |
| က | DW.50.09.3 | 365 | 210 | 212 | 50 / 2 | 17 | 20 |
| TM01 | DW.50.09.A3 | 365 | 210 | 212 | 50 / 2 | 18 | 20 |


Electrical data

| Pump type | Voltage [V] | P2 [kW] | n [min ⁻¹] | Starting method | I _N [A] | |
|----------------|----------------|------------|---------------------------|-----------------|-----------------------|-----|
| DW.50.07.1/A1 | 1 x 230 | 0.7 | 2800 | DOL | 4.0 | |
| DW.50.08.1/A1 | 1 x 230 | 0.8 | 2800 | DOL | 6.0 | |
| DW.50.08.3/A3 | 3 x 230 | 0.8 | 0.0 | 2800 | DOL | 4.3 |
| DW.50.06.3/A3 | 3 x 400 | | 2000 | DOL | 2.5 | |
| DW.50.09.3/A3 | 3 x 230 | 0.0 | 2800 | DOL | 4.5 | |
| DVV.50.09.3/A3 | 3 x 400 0.9 | | 2000 | DOL | 2.6 | |


^{*} Without cable

Performance curves/ Technical data

DW.65.27, DW.65.39, DW.100.39 and DW.100.66



Dimensions, weight and max. installation depth



| Pump type | H [mm] | D [mm] | M [mm] | S [mm] / [inch] | Weight* [kg] | Max. installation depth [m] |
|----------------|-----------|-----------|-----------|--------------------|-----------------|-----------------------------|
| DW.65.27.3 | 525 | 246 | 250 | 65 / 2 1/2 | 30 | 25 |
| DW.65.27.A3 | 525 | 246 | 250 | 65 / 2 1/2 | 30 | 25 |
| DW.65.39.3.H | 590 | 246 | 275 | 65 / 2 1/2 | 36 | 25 |
| DW.65.39.A3.H | 590 | 246 | 275 | 65 / 2 1/2 | 36 | 25 |
| DW.100.39.3 | 590 | 246 | 275 | 100 / 4 | 36 | 25 |
| DW.100.39.A3 | 590 | 246 | 275 | 100 / 4 | 36 | 25 |
| DW.100.66.3 | 710 | 264 | 275 | 100 / 4 | 51 | 25 |
| DW.100.66.A3 | 710 | 264 | 275 | 100 / 4 | 51 | 25 |
| DW.100.66.3.H | 710 | 264 | 275 | 100 / 4 | 51 | 25 |
| DW.100.66.A3.H | 710 | 264 | 275 | 100 / 4 | 51 | 25 |

Electrical data

| Pump type | Voltage [V] | P2 [kW] | n [min ⁻¹] | Starting method | Ι _Ν [Α] |
|----------------------|----------------|------------|---------------------------|-----------------|-----------------------|
| DW.65.27.3/A3 | 3 x 230 | 2.7 | 2800 | DOL | 10.7 |
| DVV.03.21.3/A3 | 3 x 400 | 2.1 | 2000 | DOL | 6.2 |
| DW.65.39.3.H/A3.H | 3 x 230 | 3.9 | 2800 | DOL | 14.9 |
| DW.00.39.3.11/A3.11 | 3 x 400 | 3.9 | 2000 | DOL | 8.6 |
| DW.100.39.3/A3 | 3 x 230 | 3.9 | 2800 | DOL | 14.9 |
| DW.100.39.3/A3 | 3 x 400 | 3.9 | 2000 | DOL | 8.6 |
| DW.100.66.3.H/A3.H | 3 x 230 | 6.6 | 2800 | DOL | 21.6 |
| DVV. 100.00.3.Π/A3.Π | 3 x 400 | 0.0 | 2000 | DOL | 12.5 |
| DW.100.66.3/A3 | 3 x 230 | 6.6 | 2800 | DOL | 21.6 |
| DVV. 100.00.3/A3 | 3 x 400 | 0.0 | 2000 | DOL | 12.5 |

^{*} Without cable

Performance curves/ Technical data


DW.100.110, DW.150.110, DW.100.200 and DW.150.200








DW.100.200/ DW.150.200



Dimensions, weight and max. installation depth




| r | Without | cable |
|---|---------|-------|

| Pump type | H [mm] | D [mm] | M [mm] | S [mm] / [inch] | Weight* [kg] | Max. installation depth [m] |
|-----------------|-----------|-----------|-----------|--------------------|-----------------|-----------------------------|
| DW.100.110.3.H | 850 | 360 | 410 | 100 / 4 | 110 | 20 |
| DW.100.110.A3.H | 850 | 360 | 410 | 100 / 4 | 110 | 20 |
| DW.150.110.3 | 850 | 360 | 410 | 150 / 6 | 110 | 20 |
| DW.150.110.A3 | 850 | 360 | 410 | 150 / 6 | 110 | 20 |
| DW.100.200.3.H | 1000 | 360 | 410 | 100 / 4 | 148 | 20 |
| DW.100.200.A3.H | 1000 | 360 | 410 | 100 / 4 | 148 | 20 |
| DW.150.200.3 | 1000 | 360 | 410 | 150 / 6 | 148 | 20 |
| DW.150.200.A3 | 1000 | 360 | 410 | 150 / 6 | 148 | 20 |

Electrical data

| Pump type | Voltage [V] | P2 [kW] | n [min ⁻¹] | Starting method | I _N [A] |
|-----------------------|----------------|------------|---------------------------|-----------------|-----------------------|
| DW.100.110.3.H/A3.H | 2 v 400 | 11 | 2800 | DOL | 21.0 |
| DW. 100. 110.3.H/A3.H | 3 x 400 | | | Y/D | 21.0 |
| DW.150.110.3/A3 | 3 x 400 | 11 | 2800 | DOL | 23.0 |
| DW. 150. 110.3/A3 | | | | Y/D | 23.0 |
| DW.100.200.3.H/A3.H | 2 × 400 | 20 | 2000 | DOL | 40 |
| DW.100.200.3.H/A3.H | 3 x 400 | | 2800 | Y/D | 40 |
| DW 450 000 0/40 | 2 400 | 20 | 2000 | DOL | 4.4 |
| DW.150.200.3/A3 | 3 x 400 | | 2800 | Y/D | 41 |

Accessories for DW pumps



104 6356 021

Fig. 16 Position of accessories


| D | Description | Product | Dimensions | | Product | | | | |
|-------|----------------------------------|---------------|--------------------|----------|---------|------------|------------------------------|--------|----------|
| Pos. | | | | DW.50.08 | DW.50 | DW.65 | DW.100 | DW.150 | number |
| 1 | Lifting chain with shackle, | 22 | 10 m | • | • | • | • | • | 96002013 |
| | | 8 200 | 6 m | • | • | • | • | • | 96003633 |
| | galvanised | Market Street | 3 m | • | • | • | • | • | 96003634 |
| | | | Rp 2 - 2" hose | • | • | | | | 96001982 |
| | | | Rp 2 1/2 - 2" hose | | | • | | | 96001983 |
| 2 | Coupling half, Storz coupling | | Rp 2 1/2 - 3" hose | | | • | | | 96002086 |
| | Otorz coupling | | Rp 4 - 4" hose | | | | • | | 96005252 |
| | | | Rp 6 - 6" hose | | | | | • | 96005253 |
| | | | 2" | • | | | | | 96005218 |
| | | | 2" | | • | | | | 96006095 |
| | | | 3" | | | • | | | 96006096 |
| 2a | Socket for hose connection | | 4" | | | (DW.65.39) | (DW.100.39) | | 96006097 |
| | Connection | | 4" | | | | (DW.100.66) | | 96005049 |
| | | | 6" | | | | (DW.100.100) (DW.100.200) | • | 96004991 |
| | | | 6" | | | | (DW.100.110) (DW.100.200) | • | 96006098 |
| | | | 10 m x 2" | • | • | | | | 96001987 |
| | | | 10 m x 3" | | | • | | | 96005254 |
| | | 11/18 | 10 m x 4" | | | | • | | 96005255 |
| 3 + 4 | Flat hose with | | 10 m x 6" | | | | | • | 96005256 |
| J + 4 | Storz coupling | | 20 m x 2" | • | • | | | | 96005257 |
| | | | 20 m x 3" | | | • | | | 96005259 |
| | | | 20 m x 4" | | | | • | | 96005260 |
| | | | 20 m x 6" | | | | | • | 96005261 |

Accessories

| | Description | Product | | | Pump type | | | | | |
|------|---|---------------|------------|----------|-------------|------------|------------------------------|--------|----------------|--|
| Pos. | | | Dimensions | DW.50.08 | DW.50.07/09 | DW.65 | DW.100 | DW.150 | Product number | |
| | Connector kit for connection of two or more DW pumps in series | - | 2" | | • | | | | 96472079 | |
| 5 | | | 3" | | | • | (DW.100.66) | | 96472100 | |
| | | | 6" | | | | (DW.100.100) (DW.100.200) | • | 96472101 | |
| - | Flat suction kit | - | | • | | | | | 96005248 | |
| - | Schuko plug | - | | • | • | | | | 96005249 | |
| | | | 2.5 - 4 A | • | • | | | | 96005250 | |
| | CEE plug with phase inverter and on/off switch | CEE plug with | 6.3 - 10 A | | | (DW.65.27) | | | 96006312 | |
| - | | - | 10 - 16 A | | | (DW.65.39) | (DW.100.39) (DW.100.66) | | 96005251 | |
| | | | 16 - 25 A | | | | (DW.100.110) | | 96005236 | |

Further product documentation

WebCAPS




WebCAPS is a **Web**-based **C**omputer **A**ided **P**roduct **S**election program available on www.grundfos.com.

WebCAPS contains detailed information on more than 185,000 Grundfos products in more than 20 languages.

In WebCAPS, all information is divided into six sections:

- Catalogue
- Literature
- Service
- Sizing
- Replacement
- CAD drawings.



Catalogue (

This section is based on fields of application and pump types, and contains


- · technical data
- curves (QH, Eta, P1, P2, etc.) which can be adapted to the density and viscosity of the pumped liquid and show the number of pumps in operation
- product photos
- dimensional drawings
- wiring diagrams
- quotation texts, etc.



Literature

In this section you can access all the latest documents of a given pump, such as

- data booklets
- installation and operating instructions
- service documentation, such as Service kit catalogue and Service kit instructions
- quick guides
- product brochures



Service (3)

This section contains an easy-to-use interactive service catalogue. Here you can find and identify service parts of both existing and discontinued Grundfos pumps.

Furthermore, this section contains service videos showing you how to replace service parts.

Further product documentation



Sizing (

This section is based on different fields of application and installation examples, and gives easy step-by-step instructions in

- select the most suitable and efficient pump for your installation
- carry out advanced calculations based on energy consumption, payback periods, load profiles, life cycle costs, etc.
- analyse your selected pump via the built-in life cycle cost tool
- determine the flow velocity in wastewater applications, etc.



Replacement

In this section you find a guide to selecting and comparing replacement data of an installed pump in order to replace the pump with a more efficient Grundfos pump.

The section contains replacement data of a wide range of pumps produced by other manufacturers than Grundfos.

Based on an easy step-by-step guide, you can compare Grundfos pumps with the one you have installed on your site. When you have specified the installed pump, the guide will suggest a number of Grundfos pumps which can improve both comfort and efficiency.



CAD drawings



In this section it is possible to download two-dimensional (2D) and three-dimensional (3D) CAD drawings of most Grundfos pumps.

These formats are available in WebCAPS:

2-dimensional drawings:

- · .dxf, wireframe drawings
- .dwg, wireframe drawings.

3-dimensional drawings:

- .dwg, wireframe drawings (without surfaces)
- .stp, solid drawings (with surfaces)
- .eprt, E-drawings.

WinCAPS



Fig. 17 WinCAPS CD-ROM

WinCAPS is a Windows-based Computer Aided Product Selection program containing detailed information on more than 185,000 Grundfos products in more than 20 languages.

The program contains the same features and functions as WebCAPS, but is an ideal solution if no Internet connection is available.

WinCAPS is available on CD-ROM and updated once a year.

Subject to alterations.

97626414 0210 GB

The name Grundfos, the Grundfos logo, and the payoff Be–Think–Innovate are registrated trademarks owned by Grundfos Management A/S or Grundfos A/S, Denmark. All rights reserved worldwide.

